

Drivers & BIOS Download Guide

How to Download Drivers and BIOS Files for Your Dynabook Laptop


Follow these simple steps to download and install the correct Drivers and BIOS files for your Dynabook laptop from the official Dynabook India website.

Step 1: Visit the Dynabook Drivers and BIOS Download Page

Go to the official Dynabook Drivers and BIOS downloads page:

<https://india.dynabook.com/drivers-bios-download/>


Step 2: Select Your Laptop Model



The screenshot shows the 'Select Laptop Model' dropdown menu open, displaying a list of laptop models. The models listed are: PORTEGE X30L-M, PORTEGE X30W-M, PORTEGE X40-M, PORTEGE X40L-M, TECRA A40-M, and TECRA A60-M. The 'Select Part Number', 'Select OS', and 'Select Type' dropdown menus are also visible but not selected.

Click on the “Select Laptop Model” dropdown — you can either start typing your Laptop Model Name or select it from the dropdown list (for example, TECRA A40-M).

Step 3: Choose the Part Number



The screenshot shows the 'Select Part Number' dropdown menu open, displaying a list of part numbers. The part number listed is: PNM13G-XXXXXX. The 'Select Laptop Model', 'Select OS', and 'Select Type' dropdown menus are also visible but not selected.


From the “Select Part Number” dropdown, choose the correct part number for your device (for example, PNM13G-XXXXXX).

Note : You can find your Part Number on the label at the base of your laptop.

When selecting, you only need to match the first six characters of the part number — the last six digits (XXXXXX) can be ignored.


Drivers & BIOS Download Guide

Step 4: Select the Operating System




Choose your Operating System version — for example, Windows 11 64-bit 24H2.

Step 5: Choose File Type



Under the “Select Type” dropdown, select whether you wish to download Drivers or BIOS files.

Step 6: Download the File



After making all selections, click on the blue Download button (e.g., TECRA A40-M (Series 1) 24H2.zip) to start downloading the Zip file.

Step 7: Extract and Install

Once the ZIP file has been downloaded:

1. Locate the downloaded .zip file on your computer.
2. Right-click the file and select ‘Extract All’.
3. After extraction, you will see a folder containing several files — similar to the example shown below.

Drivers & BIOS Download Guide

INSTALL.INI	09-10-2025 21:57	Configuration settings	19 KB
README.TXT	09-10-2025 21:56	Text Document	1 KB
TCSInstaller.exe	09-10-2025 21:56	Application	3,010 KB
PNP	09-10-2025 21:56	File folder	
COMPS1	09-10-2025 21:56	File folder	

4. To begin installation, double-click the file marked with the arrow —“TCSInstaller.exe.”
5. Follow the on-screen instructions to complete the installation.
6. Inside the extracted folder, you’ll also find a sub-folder named “COMPS1”, which contains individual driver folders (see examples below). You can access and install each driver manually if required.



Note : You can keep the downloaded ZIP file or the extracted folder saved on your computer for future use or reinstallation if required.

Need Help?

For additional assistance or troubleshooting, visit: [Dynabook Support Page](#) or contact Dynabook India : [Dynabook Contact Page](#)